

→ **Vielen Dank für das Vertrauen in unser Produkt! Bitte lies dir die Gebrauchsanleitung sorgfältig durch und bewahre sie gut auf, sie ist fester Bestandteil deines neuen BEAST ROAD STEM.**

### **Bestimmungsgemäße Verwendung**

Dein BEAST ROAD STEM eignet sich für den Einsatz an Rennrädern.

### **Montage**

Vergewissere dich vor der Montage, dass sich der Durchmesser des Gabelschaftes (1 1/8") und der Klemmdurchmesser deines Lenkers (31,8mm) für deinen BEAST ROAD STEM eignen. Schiebe die gewünschte Anzahl Spacer und anschließend den Vorbau auf den Gabelschaft. Dabei kann der Vorbau sowohl negativ (nach unten gerichtet), als auch positiv (nach oben gerichtet) montiert werden. Um eine ordnungsgemäße Klemmung zu gewährleisten, muss der Gabelschaft aus dem Vorbau herausragen und oberhalb des Vorbaus mindestens ein Spacer verbaut werden!

Montiere die Ahead-Kappe und justiere das Lagerspiel des Steuersatzes. Richte den Vorbau zum Vorderrad aus und ziehe abwechselnd die Klemmschrauben mit max. 5Nm an. Der Vorbau darf nur mit fettfreien Schrauben montiert werden. Beachte dabei die Vorgaben des Gabelherstellers! Die Verwendung der mitgelieferten Carbon-Montagepaste zwischen Schaft und Vorbau verringert das notwendige Drehmoment.

Verwende auch bei der Montage des Lenkers die mitgelieferte Carbon-Montagepaste, um das notwendige Anzugsmoment zu verringern. Richte den Lenker mittig zum Vorbau aus und drehe ihn in die gewünschte Position.

Positioniere die Klemmkappe mit der dickeren Seite nach oben und montiere alle Klemmschrauben. Ziehe zuerst die oberen Klemmschrauben mit 5Nm an, so dass der Spalt zwischen Kappe und Vorbau geschlossen ist. Ziehe danach die unteren Schrauben mit max. 5Nm an, um den Lenker sicher zu klemmen. Auf der Unterseite sollte zwischen Vorbau und Kappe ein Spalt zu sehen sein (Skizze 1).

### **Regelmäßige Wartung**

Überprüfe deine BEAST Bauteile vor Fahrtantritt stets auf Unversehrtheit. Beschädigungen können zu einem Versagen des Bauteils und damit zu schwerwiegenden Verletzungen oder sogar dem Tod führen. Defekte Bauteile sollten auf keinen Fall weiter gefahren und umgehend ausgetauscht werden.

Bei Unsicherheiten kontaktiere uns oder deinen Fachhändler.

### **Unser Versprechen**

Wir fertigen hochwertigste Produkte für dein Fahrrad und wollen dir auch den bestmöglichen Service und Support gewährleisten. Daher bieten wir dem Erstbesitzer von original BEAST Carbon-Produkten eine 5-jährige Garantie und ein lebenslanges Crash Replacement-Programm für unser gesamtes Produktsortiment.

### **5 Jahre Herstellergarantie**

Wir stehen für unsere Produkte „Made in Germany“. Daher geben wir für unsere Carbon-Produkte eine Herstellergarantie auf Material- und Verarbeitungsfehler von 5 Jahren ab Kaufdatum (Produktregistrierung erforderlich).

Modifizierte, fehlerhaft angebrachte, zweckentfremdete oder offensichtlich missbräuchlich verwendete BEAST Carbon-Produkte sind nicht von dieser Garantie abgedeckt. Die Firma Black East GmbH haftet mit dieser Garantie nicht auf Schadenersatz, insbesondere nicht für indirekte, unfallbedingte Schäden, mittelbare Schäden und Folgeschäden.

### **Lebenslanges Crash Replacement**

Wir bieten den Erstbesitzern unserer BEAST Produkte ein lebenslanges Crash Replacement-Programm, das alle Schäden (optische Beschädigungen sind ausgeschlossen) außerhalb der Gewährleistung abdeckt, egal ob selbst- oder fremdverschuldet. Wir garantieren dir in diesem Fall einen einmaligen Nachlass in Höhe von 50% auf unsere unverbindliche Preisempfehlung, wenn du dich für ein neues unserer BEAST Produkte entscheidest.

Bitte beachte, dass Mehrwertsteuer, Verpackungs-, Versand- und Montagekosten sowie etwaige Einfuhrzölle nicht abgedeckt sind (Produktregistrierung erforderlich).

# BEAST



## ROAD STEM

→ **Thanks for your trust in our product! Please read this manual carefully and keep it, because it is an inherent part of your new BEAST ROAD STEM.**

### **Intended Use**

Your BEAST ROAD STEM is suitable for the use on road racing bikes.

### **Installation**

Make sure that the diameter of your steerer tube (1 1/8") and the clamping diameter of your bar (31,8mm) is suitable for your BEAST ROAD STEM. Push the desired number of spacers and following the stem on the steerer tube. You can install your stem in a positive (showing upwards) or negative (showing downwards) way. To ensure a proper clamping, the steerer tube have to protrude over the stem and at least one spacer have to be installed on top of the stem! Install the ahead cap and adjust the bearing clearance. Align your stem to the front wheel and tighten the clamping screws alternately with max. 5Nm. The stem may only be mounted with grease-free screws! Please attend the specifications of the fork manufacturer! The usage of the included friction paste between stem and steerer tube lowers the necessary tightening torque. Use the included friction paste also at the installation of the handlebar to lower the necessary tightening torque. Align your bar centrally to the stem and rotate it into the desired position. Put the clamping cap with the thicker side on top and install the clamping screws. At first tighten the upper screws with 5Nm, that the gap between the cap and the stem is closed. After that tighten the lower screws with max. 5Nm to clamp the bar safely. There should be a gap between the cap and the stem on the bottom side (sketch 1).

### **Maintenance**

Check your BEAST part for integrity before every ride. Damages can induce a failure of the part and cause serious injuries or even death. Damaged parts shouldn't be ridden anymore and replaced immediately. If you feel not sure please contact us or your retailer.

### **Our Promise**

Just as much as we manufacture top-quality products for bikes, we strive to ensure the best possible service and support for you. Thus, we grant the original buyer of BEAST carbon products a 5-year Manufacturer Warranty and for all our products a Lifetime Crash Replacement.

### **5 Year Manufacturer Warranty**

We vouch for the quality of our products „Made in Germany“. This is why we warrant our carbon products to be free from defects in material or workmanship for five years from the original purchase date (product registration required).

Modified, misplaced, misused, improperly installed or obviously abused BEAST carbon products are not covered by this warranty. Based on this warranty, the company Black East GmbH is not liable for compensation, especially not for indirect damage caused by accidents, collateral damage and consequential damage.

### **Lifetime Crash Replacement**

We offer a Lifetime Crash Replacement Program to the original owner for BEAST manufactured products. This program covers damages which fall outside of our warranty, no matter for what reason (optical damage is excluded). As part of this program, the price of replacement BEAST products is 50% off the MSRP. Please note that sales tax, shipping, import duties, and labor are not covered by this program (product registration required).

---

**BEAST COMPONENTS**  
**BLACK EAST GMBH**

Hermann-Mende-Straße 5-7 | D-01099 Dresden |

T +49 351 50193700 | E [info@beast-components.de](mailto:info@beast-components.de) | W [www.beast-components.de](http://www.beast-components.de)

---

